


TRADITIONAL SPINNING WHEEL



TDSW-DDSW200525

Ashford Handicrafts Limited 415 West Street, Ashburton 7700 New Zealand Telephone 64 3 308 9087 Email: sales@ashford.co.nz Internet: www.ashford.co.nz

Ashford Guarantee

Thank you for purchasing this Ashford product. In the unlikely event there is any fault in manufacture, please contact the dealer you purchased it from. To validate the guarantee, please go to www.ashford.co.nz/product-registration

ASSEMBLY INSTRUCTIONS FOR THE ASHFORD TRADITIONAL SPINNING WHEEL


Before commencing, please read these instructions completely, identify the parts and note the assembly sequence.

Remove any sharp corners or edges and smooth the surface of the wood with the sand paper provided. We recommend that the wood surfaces be waxed or sealed before assembly. This protects the kiln dried wood from climatic changes and prevents it getting dirty or stained. The Beech timber has a lovely variety of colour and grain. For a silky smooth matt finish, use Ashford Finishing Wax Polish to enhance the natural colours and character of this timber.

If you are assembling your spinning wheel on a table, we recommend you protect the surface with a towel, blanket or cardboard.

Ashford spinning wheels are also available factory finished in clear lacquer.

Tools Required



More Information




How-to videos on You Tube Watch our how-to videos on You Tube. @AshfordNZ




Blog


For inspirational articles, patterns and projects. Subscribe for free to the Ashford Blog www.ashford.co.nz/blog


Facebook Join us on facebook ashford.wheels.looms






Check the angle of the side rails and tighten.











4

P1

Loosely attach the wheel support to the side rails with bolts and barrel nuts. Then locate the treadle rail into the holes in the legs.












Insert the crank shaft into the wheel support. Tighten every bolt extra firmly with the Hex wrench. Then remove the crank. Hint: Store the Hex wrench so the bolts can be tightened again in the future.







Before placing the wheel in position, check the crank fits through the hole in the hub. Wax and insert the crank shaft then remove.





Place the wheel in position.







Note: The ball bearings are sealed for life and <u>do</u> not require oiling.



SINGLE DRIVE Step 12 - 21 For Single Drive only. For Double Drive go to Step 22.




Assemble the flyer unit. Check the shape of the nylon bearing on each maid upright, wax the dowel ends, then insert into the correct hole. Insert the drive belt adjusting knob into the maiden bar, turn until the end just protrudes.






Check the angle of the nylon bearings. Then secure the maid uprights with screws and washers. Do not overtighten. The maid uprights may be twisted to remove the bobbin.

Position the drawing pin directly beneath the drive band adjusting knob.








Apply a drop of oil to the flyer shaft and slide the small end of the bobbin on first. Ashford spinning wheel oil is ideal for this purpose. Then locate the flyer into the bearings. Thread the screw eye into the side of the maiden bar, and screw hook into the opposite side.







Attach the brake band. Thread it through the screw eye and then tie the springs as illustrated.








Put the brake band over the grooved end of the bobbin. Do not over stretch the springs.















Attach the flyer unit to the side rails with 2 screws and washers, do not tighten yet.

Move the flyer unit until the wheel and large flyer pulley are aligned. Then tighten the screws. Check!








Check the end of the adjusting knob is not protruding beneath the maiden bar. Then place the drive belt around the wheel and large flyer pulley. Tie the drive belt and cut off the extra.








Single drive ratios:

The ratio with the drive belt around the large flyer pulley is approx. 7:1.


To spin a finer yarn while treadling at the same speed, move the drive belt to one of the centre pulleys - either 9:1 or 12:1.

To spin a very fine yarn, move the drive belt onto the small flyer pulley and re-tension it. This ratio is approx. 17:1.



DOUBLE DRIVE


Step 22 - 32 For Double Drive only. For Single Drive go to Step 12.





Assemble the flyer unit. Check the shape of the nylon bearing on each maiden upright, wax the dowel ends, then insert into the correct hole.


Insert the drive belt adjusting the knob into the maiden bar, turn until the end just protrudes.






Check the angle of the nylon bearings. Then secure the maid uprights with screws and washers. Do not overtighten. The maid uprights may be twisted to remove the bobbin.

Position the drawing pin directly beneath the drive band adjusting knob.







Apply a drop of oil to the flyer shaft and slide the bobbin on. Ashford spinning wheel oil is ideal for this purpose.

Partially locate the whorl onto the flyer shaft and rotate the whorl until the flat on the flyer shaft aligns with the flat in the whorl. Then push the whorl on.

Caution: Do not twist the whorl, only slide the whorl on or off. If it is tight apply a drop of oil to the end of the flyer shaft.


To change the bobbin, grip the whorl with one hand and the flyer with the other and pull the whorl directly off.


Then locate the flyer into the bearings.

Thread the screw eye into the side of the maiden bar, and screw hook into the opposite side.










27 ()


This wheel can be used either double drive or single drive.

When spinning double drive the brake band is stored around the back of the maid upright with the drive band around both the large flyer pulley and small bobbin pulley.

When spinning single drive the drive band is around the large flyer pulley and the brake band is over either bobbin pulley. When using the brake band take care not to over-stretch the springs.




Check!








Attach the flyer unit to the side rails with 2 screws and washers, do not tighten yet.


Move the flyer unit until the wheel and large flyer pulley are aligned. Then tighten the screws.















Single drive:


Place both loops of the drive belt around the large flyer pulley and the brake band over either bobbin pulley. Adjust the brake band tension so the springs only just begin to stretch.

To spin a finer yarn move both loops of the drive belt onto the small flyer pulley and re-tension it.





Memo





Ashford Handicrafts Limited 415 West Street, Ashburton 7700 New Zealand Telephone 64 3 308 9087 Email: sales@ashford.co.nz Internet: www.ashford.co.nz