



415 West Street, P.O. Box 474, Ashburton, New Zealand
Phone: (64-03) 308 9087 + Fax: (64-03) 308 8664.

Ashford Table Loom Floor Stand MK2 for 410, 610 and 800 mm wide looms

Assembly instructions

Tools Required:

Screwdriver

Note: if your loom does not have holes pre-drilled in the sides, please obtain a 6.5 mm (1/4") drill, and drill holes 250 mm (9 3/4") in from the back and 95 mm (3 3/4") in from the front. Make sure the holes are drilled in the middle (of the narrow width) of the rails.

Before Commencing: Read the instructions completely, identify the parts and note the assembly sequence.

Finishing the Wood: We recommend the wood be 'sealed' prior to assembly. This protects the kiln dried wood from climatic changes and enhances its appearance. Use the garnet paper supplied to remove sharp edges and corners. After sanding apply a wood finish. **Ashford Wax available** - ideal formula for preserving and enhancing the natural timber.

ASSEMBLY

Step 1: Attach the two short legs to the cross rail with screws. **Note:** the Ashford logo should face up.

Step 2: Join the legs together by pushing a long bolt from the outside through the third hole in the outside leg, through a spacer block and third hole from the bottom in the inside leg. Secure with washer and wing nut. Repeat for the opposite side. **Note:** the holes at the end of the outside legs allow for the treadle kit to be attached at a later date.

Step 3: Lie the loom upside down on the rear beam and castle top rail. Attach the four legs to the loom sides with the short bolts, washers and wing nuts.

Step 4: We recommend removing the front spacer rail to allow more room for your knees when weaving.

Step 5: To alter the height or angle of the loom, simply lie the loom on its back and move the long bolt up or down the holes in the legs.

Designed and manufactured by:

ASHFORD HANDICRAFTS LTD

