

SampleIt Loom Stand

For the SampleIt Loom 25cm (10ins) and 40cm (16ins)



SL25LS130918V2

ASSEMBLY INSTRUCTIONS

- 1. Attach the base rail (with the Ashford logo) to one side and one foot and secure with a small washer and knob. Note the tapered side fits snugly into the tapered rebate in the foot. Tighten the knobs to make the joint tight.
- 2. Attached the other side and foot. Secure with a small washer and knob.
- 3. Push the 2 bolts through the holes in the side of the Samplelt loom. Locate the bolts into the grooves in the top on the loom stand and secure with large washers and knobs.
- 4. Sit at the loom with your feet on the base rail. Loosen the knobs and tilt the loom until it is resting on your knees. Then re-tighten the knobs.

Now enjoy weaving on your SampleIt loom.

