



Use the small wooden block supplied to assist inserting the clicker pins.



Push the clicker pin 1 – 2mm (1/16") into the hole in the side.

Slide the wooden block over the pin and push it down so it is flat on the surface of the side. This will ensure the clicker pin is inserted vertically.

Use a hammer and lightly tap the pin until it is level with the top of the wooden block. This will ensure the clicker pin is inserted to the correct depth.