

TURBO KIT POLYCORD

FOR ALL ASHFORD SINGLE DRIVE SPINNING WHEELS

The polycord drive belt will give you and your wheel a boost.

- Makes treadling easier with low drive belt tension
- Less friction on the wheel and flyer bearings
- More traction, especially on the smaller flyer whorls
- Easy drive belt adjustment - set and forget
- Makes plying a breeze, especial with chunky yarns.

Here's how you fit your new Turbo kit:

1. Ensure the maiden bar is set to it's lowest point. Place the polycord drive belt around the wheel and largest pulley on the flyer.
2. Mark the polycord where it is just the right length without stretching it. Note: Do not make it tight.
3. Cut off the excess polycord with a razor blade, sharp knife or scissors and save it for future repairs or adjustments.
4. Before joining, place the cord back around the wheel.
5. Hold the two ends close to the base of the flame of a candle or gas lighter until the ends start to melt. The flame at the base is cleaner and results in a clear joint.
6. Then quickly press the ends tightly together in the groove in the wooden fusing block. Hold firmly for about 30 seconds or until the polycord has cooled.
7. Use a razor blade or nail clippers to trim off the excess material around the joint.
8. Adjust the tension knob so the polycord tension is as loose as possible without actually slipping.

TURBO KIT POLYCORD

TKP



Batch #

Packed

Ashford Guarantee

Thank you for purchasing this Ashford product. In the unlikely event there is any fault in manufacture, please contact the dealer you purchased it from. To validate the guarantee, please go to www.ashford.co.nz/product-registration