

SHUTTLE RACE

410/610/800mm
16/24/32in

Congratulations your loom includes a Shuttle Race.

1. To attached the Shuttle Race tie a knot in one end of the stretchy cords and thread the unknotted end through the bottom hole in the beater arm, up the back and through the top hole.
2. Then down through the hole in the Shuttle Race and tie a knot loosely so it can be undone and adjusted later.
3. Repeat for the other side.
4. Hold the Shuttle Race against the reed and pull the knot out from the beater arm, through the slot in the end of the Shuttle Race and position the knot into the notch. Repeat for the other side.
5. Adjust the position of the knots underneath to increase or decrease the flexibility of the Shuttle Race. The Shuttle Race should flex down when you gently press it. This is so it can flex out of the way when you are beating.

NOTE: For convenience when dressing the loom and threading the reed, the Shuttle Race can be dropped down out of the way by removing the bungy cord from the slot.

